

SCTE • ISBE[®]

S T A N D A R D S

Data Standards Subcommittee

SCTE STANDARD

SCTE 165-11 2019

IPCablecom 1.5 Part 11: Analog Trunking for PBX Specification

NOTICE

The Society of Cable Telecommunications Engineers (SCTE) / International Society of Broadband Experts (ISBE) Standards and Operational Practices (hereafter called “documents”) are intended to serve the public interest by providing specifications, test methods and procedures that promote uniformity of product, interchangeability, best practices and ultimately the long-term reliability of broadband communications facilities. These documents shall not in any way preclude any member or non-member of SCTE•ISBE from manufacturing or selling products not conforming to such documents, nor shall the existence of such standards preclude their voluntary use by those other than SCTE•ISBE members.

SCTE•ISBE assumes no obligations or liability whatsoever to any party who may adopt the documents. Such adopting party assumes all risks associated with adoption of these documents, and accepts full responsibility for any damage and/or claims arising from the adoption of such documents.

Attention is called to the possibility that implementation of this document may require the use of subject matter covered by patent rights. By publication of this document, no position is taken with respect to the existence or validity of any patent rights in connection therewith. SCTE•ISBE shall not be responsible for identifying patents for which a license may be required or for conducting inquiries into the legal validity or scope of those patents that are brought to its attention.

Patent holders who believe that they hold patents which are essential to the implementation of this document have been requested to provide information about those patents and any related licensing terms and conditions. Any such declarations made before or after publication of this document are available on the SCTE•ISBE web site at <http://www.scte.org>.

All Rights Reserved

© Society of Cable Telecommunications Engineers, Inc.
140 Philips Road
Exton, PA 19341

Table of Contents

1	INTRODUCTION	5
1.1	SCOPE	5
1.2	RELATIONSHIP TO OTHER IPCABLECOM SPECIFICATIONS	5
1.3	NCS PACKAGE REQUIREMENTS	6
1.4	REQUIREMENTS AND CONVENTIONS	6
2	REFERENCES	7
2.1	NORMATIVE REFERENCES	7
2.2	INFORMATIVE REFERENCES	7
3	TERMS AND DEFINITIONS	8
4	ABBREVIATIONS AND ACRONYMS	9
5	OVERVIEW	10
5.1	FUNCTIONAL RESPONSIBILITY	10
5.2	PHYSICAL ENDPOINT INTERFACE	10
5.2.1	<i>Loop-Start Line Interface</i>	10
5.2.2	<i>Ground-Start Line Interface</i>	10
5.2.3	<i>DID PBX Trunk Interface</i>	11
5.2.4	<i>E&M</i>	11
5.3	NCS PACKAGE SUPPORT	12
6	ANALOG TRUNKING FOR PBX FUNCTIONAL REQUIREMENTS	13
6.1	ENDPOINT CONFIGURATION	13
6.1.1	<i>Physical Interface Type Configuration</i>	13
6.1.2	<i>PBX Trunk Type Configuration</i>	14
6.1.3	<i>Start of Dialing Method Configuration</i>	14
6.1.4	<i>Out-pulse Dialing Method</i>	14
6.1.5	<i>Maximum Out-pulsed Dial String Length</i>	14
6.1.6	<i>Re-seizure Delay</i>	15
6.2	SIGNALING SUPPORT	15
6.2.1	<i>Digit and Digit Related Events</i>	16
6.2.2	<i>Digit Events over E&M</i>	16
6.2.3	<i>Local Tones</i>	17
6.2.4	<i>Caller ID and VMWI</i>	17
6.2.5	<i>Hook Events</i>	17
6.2.6	<i>Open Signal Interval</i>	18
6.2.7	<i>Ring Requests</i>	18
6.2.8	<i>T1 Trunk Signaling Requirements</i>	18
ANNEX A	EVENT PACKAGES (NORMATIVE)	19
A.1	IPCABLECOM ANALOG TRUNKING FOR PBX PACKAGE	19
ANNEX B	SAMPLE CALL FLOWS (INFORMATIVE)	23
B.1	CALL SETUP CALL FLOW EXAMPLE	23
B.2	CALL TEARDOWN CALL FLOW EXAMPLE	27
B.3	CALL BLOCK/RELEASE CALL FLOW EXAMPLE – NETWORK INITIATED	29
B.4	CALL BLOCK/RELEASE CALL FLOW EXAMPLE – PBX INITIATED	31

List of Figures

FIGURE 1 – GROUND-START LINE AND LOOP TRUNK INTERFACES5

List of Tables

TABLE 1 – INTERFACE REQUIREMENTS MATRIX13
TABLE 2 – NCS LINE PACKAGE SUPPORT15
TABLE 3 – PAT PACKAGE CODES FOR EVENTS AND SIGNALS19
TABLE 4 – CALL SETUP PARAMETERS.....21
TABLE 5 – PBX SEQUENCING DURING CALL SETUP (SINGLE STAGE)22
TABLE 6 – PBX SEQUENCING DURING CALL SETUP (MULTI-STAGE)22

1 INTRODUCTION

This specification defines extensions to the IPCablecom Network-based Call Signaling [NCS] protocol to support the following analog trunking for PBX interfaces on an embedded Voice-Over-IP client device in an IPCablecom environment:

- Ground-start lines
- PBX one-way and two-way DTMF trunks

1.1 Scope

As shown in Figure 1 below, the IPCablecom NCS specification [NCS] already defines the Loop-Start line interface typically used for residential services today. This specification is designed for additional line/trunk interfaces to support analog trunking for PBX so that the MTA may be used to interface directly to a Legacy PBX via a Ground-Start line or other trunk interface (E&M or DID). Example PBX trunk interfaces are shown below.




Figure 1 – Ground-Start Line and Loop Trunk Interfaces

1.2 Relationship to Other IPCablecom Specifications

Analog Trunking for PBX is defined here as a supplement to the IPCablecom NCS interface. Though this specification is included as part of the IPCablecom 1.5 release, the features specific to IPCablecom 1.5 are not required to support analog trunking for PBX. The capabilities defined in this specification may be supported by components that conform to the IPCablecom 1.0 release. Full support for the IPCablecom 1.5 release is RECOMMENDED for analog trunking for PBX due to the inclusion of additional features such as [T.38] and [RFC 2833].

1.3 NCS Package Requirements

The IPCablecom analog trunking for PBX (PAT) package is defined in this specification as an extension to the NCS Line package to provide the needed functionality specific to analog trunking for PBX. Both packages are required to support analog trunking for PBX. It should be noted that the PAT package is designed in such a way as to provide a complete abstraction of the physical characteristics of an endpoint to the Call Agent. For example, the Call Agent is unaware of the physical endpoint interface (e.g., E&M or DID), start of dialing method (e.g., wink start), and out-pulse dialing type (e.g., DTMF). This abstraction exists due to time-to-market considerations. As such, the endpoint is required to alter its behavior based on these physical characteristics given a particular command from the Call Agent. In some cases this behavior breaks the general rules of NCS. The exceptions to NCS are documented in this specification and apply only to analog trunking for PBX.

1.4 Requirements and Conventions

Throughout this document, the words that are used to define the significance of particular requirements are capitalized. These words are:

"MUST"	This word means that the item is an absolute requirement of this specification.
"MUST NOT"	This phrase means that the item is an absolute prohibition of this specification.
"SHOULD"	This word means that there may exist valid reasons in particular circumstances to ignore this item, but the full implications should be understood and the case carefully weighed before choosing a different course.
"SHOULD NOT"	This phrase means that there may exist valid reasons in particular circumstances when the listed behavior is acceptable or even useful, but the full implications should be understood and the case carefully weighed before implementing any behavior described with this label.
"MAY"	This word means that this item is truly optional. One vendor may choose to include the item because a particular marketplace requires it or because it enhances the product, for example; another vendor may omit the same item.

2 REFERENCES

The following documents contain provisions which, through reference in this text, constitute provisions of this standard. At the time of Subcommittee approval, the editions indicated were valid. All documents are subject to revision, and while parties to agreement based on this standard are encouraged to investigate the possibility of applying the most recent editions of the documents listed below, they are reminded that newer editions of those documents might not be compatible with the referenced version.

2.1 Normative References

In order to claim compliance with this standard, it is necessary to conform to the following standards and other works as indicated, in addition to the other requirements of this standard. Intellectual property rights may be required to implement these references.

- [ANSI 401] ANSI T1.401-2000 Interface Between Carriers and Customer Installations – Analog Voicegrade Switched Access Lines Using Loop-Start and Ground-Start Signaling.
- [ANSI 405] ANSI T1.405-2002 Network-to-Customer Installation Interfaces - Direct Inward Dialing Analog Voicegrade Switched Access Using Loop Reverse-Battery Signaling.
- [GR 505] GR-505, Call Processing, December 1997, Telcordia.
- [GR 506] GR-506, LSSGR: Signaling for Analog Interfaces, June 1996. Telcordia.
- [NCS] ANSI/SCTE 165-3 2016, IPCablecom 1.5 Part 3: Network-Based Call Signaling Protocol.
- [TIA] EIA/TIA-464-C Telecommunications - Multiline Terminal Systems Requirements for PBX Switching Equipment, June 2004.

2.2 Informative References

The following documents may provide valuable information to the reader but are not required when complying with this standard.

- [ANSI 403] ANSI T1.403-1999 Network-to-Customer Installation Interfaces – DS-1 – Electrical Interface.
- [RFC 2833] IETF RFC 2833, RTP Payload for DTMF Digits, Telephony Tones and Telephony Signals, May 2000.
- [RFC 3064] IETF RFC 3064, MGCP CAS Packages, February 2001.
- [RFC 3435] IETF RFC 3435, Media Gateway Control Protocol (MGCP) Version 1.0, January 2003.
- [SDP] IETF RFC 2327, Session Description Protocol (SDP), April 1998.
- [T.38] ITU-T Recommendation T.38, Procedures for Real-Time Group 3 Facsimile Communication over IP Networks, April 2004.
- [TR-NWT-000031] Telcordia TR-NWT-000031, Issue 4, CLASS Feature: Calling Number Delivery, December 1992.
- [TR-NWT-001188] Telcordia TR-NWT-001188, Issue 1, CLASS Feature: Calling Name Delivery, December 1991.

3 TERMS AND DEFINITIONS

This specification uses the following terms:

- Endpoint** A Terminal, Gateway or Multipoint Conference Unit (MCU).
- Gateway** Devices bridging between the IPCablecom IP Voice Communication world and the PSTN. Examples are the Media Gateway, which provides the bearer circuit interfaces to the PSTN and transcodes the media stream, and the Signaling Gateway, which sends and receives circuit switched network signaling to the edge of the IPCablecom network.
- Trunk** An analog or digital connection from a circuit switch that carries user media content and may carry voice signaling (MF, R2, etc.).

4 ABBREVIATIONS AND ACRONYMS

This specification uses the following abbreviations:

CAS	Channel Associated Signaling
CMS	Call Management Server
CMTS	Cable Modem Termination System
DID	Direct Inward Dialing
DOD	Direct Outward Dialing
DTMF	Dual-tone Multi Frequency (tones)
GS	Ground-start
LS	Loop-start
MTA	Multimedia Terminal Adapter
NCS	Network-based Call Signaling
PBX	Private Branch Exchange
PAT	IPCablecom Analog Trunking (package)
RLCF	Reverse Loop Current Feed

5 OVERVIEW

This specification describes the functional requirements for an embedded client to support one-way incoming, one-way outgoing, and two-way PBX trunks. The physical interfaces used to support these trunk types are also defined.

5.1 Functional Responsibility

To maintain compliance with the IPCablecom NCS specification [NCS], the Call Agent will remain responsible for all higher order functionality whenever possible. Only when timing is critical will the endpoint be responsible for the required functionality. For example, the endpoint is expected to out-pulse a string of successive digits when requested by the Call Agent. In this case, the endpoint is responsible for the timing of the duration of each digit and the delay between them.

The endpoint is also responsible for all timing requirements related to the start method in use – wink, delay or immediate. In fact, the start method used by the interface is transparent to the Call Agent.

5.2 Physical Endpoint Interface

Various physical interfaces provided by an endpoint of an MTA are used to support the following PBX trunks:

- One-way incoming trunk – supports calls originating from the network towards the PBX via the MTA. A specific example of a one-way incoming trunk is a DID PBX trunk which **MUST** be provided using a DID PBX physical interface.
- One-way outgoing trunk – supports calls originating on the PBX towards the network via the MTA. A specific example of a one-way outgoing trunk is a DOD PBX trunk which **MAY** be provided over a number of physical interfaces.
- Two-way trunk – supports calls originating and terminating on the PBX via the MTA. A four-wire E&M physical interface is typically used to support two-way PBX trunks; however, other interfaces **MAY** also be used.

The following sections describe each physical interface that may be provided on an MTA to support one or more of the above defined PBX trunks.

5.2.1 Loop-Start Line Interface

The NCS Line package defined in the IPCablecom NCS specification [NCS] is used to support loop-start lines. Loop-start lines are typically used for residential voice services, but **MAY** be used to support analog trunking for PBX.

5.2.2 Ground-Start Line Interface

Ground-start signaling interfaces are used to provide two-way service to customer-installation switching systems, e.g., legacy PBX systems.

According to [ANSI 401] ground-start signaling for two-way dial facilities was introduced to reduce the likelihood of seizure of the line at both ends during the silent interval of the alerting signal. Ground-start signaling is typically used on one-way or two-way seizure PBX lines with Direct Outward Dialing (DOD) and attendant-handled incoming call service. Ground-start lines are also used for automatically originated data service. The two-wire ground-start line conductors transmit common-battery loop supervision, loop dial pulses or DTMF address signals, alerting signals, and voice-band signals. Ground-start lines are often used rather than loop-start lines for the following reasons:

- To avoid simultaneous seizure, i.e., glare conditions.
- To allow the application of a dc voltage between tip and ring and the closure of a path from the tip conductor to ground as a start dial signal.
- To provide a positive indication of network disconnect.

See [ANSI 401] for the network interface requirements for ground-start access lines.

5.2.3 DID PBX Trunk Interface

A one-way Direct Inward Dialing (DID) trunk interface as described in [TIA] is required to support a DID interface of a PBX. DID trunks can only make calls in the direction from the network towards the PBX.

Electrically, a DID trunk looks similar to the reverse of a 2-wire loop-start interface. The PBX provides loop current by applying -48 volt battery to the ring lead and grounding the tip lead. The MTA signals off-hook and on-hook towards the PBX by closing and opening the loop. The PBX signals answer supervision (off-hook) by reversing battery and ground on the tip and ring leads [ANSI 405]. The PBX signals call release (on-hook) by restoring battery to ring and ground to tip. Since this is a one-way trunk, there is no ringing voltage as seen on a loop-start interface.

The MTA may dial using either dial-pulse at 10 pulses per second with 300 ms between digits or DTMF at 10 tones per second. Dial-pulse may be done either by opening and closing the loop in a manner similar to loop-start dialing; or it may use battery and ground pulsing. With dial-pulse interfaces, the network typically only dials the last 2 or 3 address digits to minimize call setup delay.

The interface has three methods for start of dialing:

- Immediate start – The MTA starts dial-pulsing shortly after closing the loop indicating off-hook condition. This method cannot be used for DTMF.
- Wink start – The MTA waits for the PBX to signal that it is ready to accept digits. The signal from the PBX is a 200 ms battery reversal (off-hook).
- Delay start – The MTA waits for the PBX to signal that it is ready to accept digits. The signal from the PBX is a battery reversal of at least 100 ms (off-hook) followed by restoration of battery (on-hook) some time later.

Of the three start-of-dialing methods, wink start is most common.

5.2.4 E&M

E&M is described in Annex F of [TIA] and is typically used as a PBX tie trunk. E&M trunks may be configured to be 2-way or 1-way. Signaling may be either dial pulse or DTMF. The interface is extremely simple and only off-hook and on-hook are signaled in each direction. The PBX signals off-hook and on-hook on the M-lead (Mouth) and listens for off-hook and on-hook signals on the E-lead (Ear). The three dialing methods found in DID are also used in E&M.

The interface has three methods for start of dialing:

- Immediate start – The calling side of the interface goes off-hook. It starts dial pulsing shortly afterwards (at least 65 mSec). This method cannot be used for DTMF.
- Wink start – The calling side goes off-hook and waits for the called side to signal that it is ready to accept digits. The signal from the called side is a 200 mSec off-hook wink.
- Delay start – The calling side goes off-hook and waits for the called side to signal that it is ready to accept digits. The signal from the called side is an off-hook transition within 150 mSec of detecting off-hook and lasting at least 140 mSec followed by an on-hook some time later.

Answer supervision is transmitted on the called side by a transition to off-hook.

Release supervision is transmitted by a transition to on-hook.

5.2.4.1 Two-wire E&M

Two-wire E&M (or Type I E&M) has two conductors on the interface called the E-lead (or Ear) and the M-lead (or Mouth). The PBX provides -48 volt battery on both leads. The MTA signals off-hook by shorting the PBX E-lead to ground. The PBX signals off-hook by closing a contact to provide battery to the M-lead.

5.2.4.2 Four-wire E&M

Four-wire E&M (Type II E&M) has four conductors called the E-Lead, the M-Lead, Sleeve Battery, and Sleeve Ground. The PBX applies -48 volt battery to the E-Lead and grounds the Sleeve Ground. The MTA provides -48 volt battery on the Sleeve Battery and grounds the M-Lead with a current detector. The MTA signals off-hook by shorting the E-Lead to Sleeve Ground. The PBX signals off-hook by shorting the M-Lead to Sleeve Battery.

5.3 NCS Package Support

In order to avoid the unnecessary complexity of supporting redundant signals and events, an additional package above and beyond the NCS Line package is defined here to include only those events and signals that are needed to support analog trunking for PBX, but do not already exist in the NCS Line package. Due to this design, the PAT package relies heavily on the NCS Line package. In other words, both packages **MUST** be supported when providing analog trunking for PBX.

As shown in Table 1 below, support for the NCS Line package is required regardless of the interface type and service provided. Support for the PAT package is required only for analog trunking for PBX.

6 ANALOG TRUNKING FOR PBX FUNCTIONAL REQUIREMENTS

In general, support for analog trunking for PBX as defined in this specification is optional, i.e., not required for IPCablecom compliancy. Analog Trunking for PBX is an add-on to existing functionality already defined in other IPCablecom specifications.

Table 1 describes the support required based on the physical interface type. In some cases the configuration parameter does not apply to the particular interface or trunk type. In this case, the parameter is marked as "Not Needed".

Table 1 – Interface Requirements Matrix

Interface Type	Trunk Type	NCS Package Support		Start of Dialing Method	Out-pulse Dialing Method	Max Length of Out-pulse Dial String
		Line	PAT			
Loop-Start	Residential voice	Yes	No	Dial tone	Not Needed	Not Needed
	1-way incoming	Yes	Yes	Not Needed	Needed	Needed
	1-way outgoing	Yes	Yes	Dial tone	Not Needed	Not Needed
	2-way	Yes	Yes	Dial tone	Needed	Needed
Ground-Start	1-way incoming	Yes	Yes	Not Needed	Needed	Needed
	1-way outgoing	Yes	Yes	Dial tone	Not Needed	Not Needed
	2-way	Yes	Yes	Dial tone	Needed	Needed
DID PBX	1-way incoming	Yes	Yes	Needed	Needed	Needed
E&M	1-way incoming	Yes	Yes	Needed	Needed	Needed
	1-way outgoing	Yes	Yes	Needed	Not Needed	Not Needed
	2-way	Yes	Yes	Needed	Needed	Needed
T1	1-way incoming	Yes	Yes	Needed ¹	Needed	Needed
	1-way outgoing	Yes	Yes	Needed ¹	Not Needed	Not Needed
	2-way	Yes	Yes	Needed ¹	Needed	Needed

6.1 Endpoint Configuration

To support the trunk types defined in Section 5.2, the endpoint MUST be configured with the following:

- Physical interface type
- PBX Trunk type
- Start of dialing method
- Out-pulse dialing method
- Maximum length of out-pulsed dial string
- Re-seizure delay

6.1.1 Physical Interface Type Configuration

At any given point in time, an endpoint supports one and only one type of interface:

- Loop-start line interface

¹ For T1 the start method depends on the physical interface being emulated.

- Ground-start line interface
- E&M 2-wire line interface
- E&M 4-wire line interface
- DID PBX trunk interface
- T1

The question of how a particular endpoint is configured for a particular interface type is beyond the scope of this specification. For example, the endpoint MAY be configured via provisioning or separate MTA hardware used to provide the interface requirements defined here. The only point is that an endpoint – once configured – will provide one type of interface.

See Section 5.2 for the interface requirements between the MTA and the PBX.

6.1.2 PBX Trunk Type Configuration

As stated in Section 5.2, the following PBX trunk types are supported:

- One-way incoming trunk
- One-way outgoing trunk
- Two-way trunk

The endpoint MUST be configured as such when used to interface to a PBX to provide one of the above trunk types. When this configuration information is missing, the default behavior is to provide residential voice service, which may or may not be applicable to the physical interface (see Table 1 above).

6.1.3 Start of Dialing Method Configuration

In order for the MTA to provide an interface to a PBX using either a PBX DID or E&M physical interface, the start of dialing method MUST be configured to something other than the default "dial tone" method. The configured start of dialing method for two-way E&M PBX trunks is used in both directions – PBX to endpoint and endpoint to PBX. For loop-start and ground-start lines the default "dial tone" method MUST be used which indicates that dial tone is provided as a signal to the PBX to start dialing. The start of dialing methods in which the endpoint may be configured are as follows:

- Dial tone (default)
- Immediate start
- Wink start
- Delay start

6.1.4 Out-pulse Dialing Method

When an endpoint is configured to support incoming PBX calls, the endpoint will be expected to out-pulse a dial string towards the PBX. In this case, the endpoint MUST be configured to out-pulse one of the following digit types:

- DTMF
- Dial Pulse

6.1.5 Maximum Out-pulsed Dial String Length

The Call Agent may provide the entire external phone number of the extension being dialed in the PBX. Typically, however, only the last few digits are needed. As such, the endpoint MUST be configured with the maximum dial string length when configured to support incoming PBX calls. When the Call Agent provides a dial string that exceeds the maximum length configured, the endpoint MUST out-pulse only the last digits received up to the

configured maximum length. For example, let's say that the maximum out-pulsed dial string length is configured to be four and the Call Agent provides the following dial string to out-pulse:

(1, 7, 7, 0, 5, 5, 5, 1, 2, 1, 2)

The endpoint would out-pulse only the last four digits in this case (1, 2, 1, 2).

The maximum out-pulsed dial string length is limited to 32 digits.

6.1.6 Re-seizure Delay

Due to PBX requirements once a trunk is released it cannot be seized again for a short period of time. The MTA MUST be configured with the amount of time required to wait (in mSec). The default is zero, i.e., no delay. The MTA MUST not re-seize a trunk during this period of time. If a new Call Setup request is received during this time, the MTA MUST delay execution of the command until such time has passed. The command MUST NOT, however, be rejected due to this requirement.

6.2 Signaling Support

In order to help quickly detect configuration issues (e.g., endpoint is configured for residential voice while the Call Agent is configured for PBX service), commands issued to the endpoint that are specific to a particular service MUST be rejected when the endpoint is configured to support any other service. The reverse is also true. If the endpoint notifies an event that is specific to a service other than its current configuration via the Call Agent, then the Call Agent MUST reject the NTFY.

When an endpoint is configured for residential voice, independent of the physical interface, support for the PAT package MUST be suppressed. As such, the endpoint MUST NOT include the PAT package in the list of supported packages when audited via the AUEP command. An endpoint that is requested to detect an event or apply a signal that is specific to the PAT package MUST return an error (error code 518 – unsupported or unknown package).

When an endpoint is configured to be a one-way or two-way PBX trunk, independent of the physical interface, the PAT package MUST be fully supported. When endpoint capabilities are audited via the AUEP command, the PAT package MUST be included in the list of supported packages. The default NCS Line package MUST also be included. If however, the endpoint is requested to detect an event or apply a signal included in the NCS Line package according to Table 2 below that the interface is unable to support an error MUST be returned (error code 512 or 513 – not equipped to detect event or generate signal). Some signals/events that are shown to be "not required" are allowed to be requested by the Call Agent. The endpoint MUST apply the signal or process the event as requested if the endpoint is physically capable of doing so.

Note that the T1 physical interface is not listed in Table 2. The required signaling support for T1 mirrors the physical interface being emulated.

Table 2 – NCS Line Package Support

NCS Line Package Signal / Event	Required for...			
	LS Residential Voice	LS/GS PBX Trunk	E&M PBX Trunk	DID PBX Trunk
0-9,*,#,A,B,C,D	Yes	Yes	Yes	No
bz	Yes	Yes	Yes	Yes
cf	Yes	No	No	No
ci(ti, nu, na)	Yes	No	No	No
dl	Yes	Yes	Yes	No
ft	Yes	Yes	Yes	Yes
hd	Yes	Yes	Yes	Yes
hf	Yes	Yes	Yes	Yes

NCS Line Package Signal / Event	Required for...			
	LS Residential Voice	LS/GS PBX Trunk	E&M PBX Trunk	DID PBX Trunk
hu	Yes	Yes	Yes	Yes
L	Yes	Yes	Yes	No
ld	Yes	Yes	Yes	Yes
ma	Yes	Yes	Yes	Yes
mt	Yes	Yes	Yes	Yes
mwi	Yes	No	No	No
oc	Yes	Yes	Yes	Yes
of	Yes	Yes	Yes	Yes
osi	Yes	No	No	No
ot	Yes	No	No	No
r0, r1, r2, r3, r4, r5, r6 or r7	Yes	No	No	No
rg	Yes	No	No	No
ro	Yes	Yes	Yes	Yes
rs	Yes	No	No	No
rt	Yes	Yes	Yes	Yes
sl	Yes	No	No	No
t	Yes	Yes	Yes	No
TDD	Yes	Yes	Yes	Yes
vmwi	Yes	No	No	No
wt1, wt2, wt3, wt4	Yes	No	No	No
X	Yes	Yes	Yes	No

There are some special considerations related to the use of the NCS Line package with analog trunking for PBX as detailed in the sections below.

6.2.1 Digit and Digit Related Events

When the endpoint is expected to receive digits from the PBX and the Call Agent is to be notified of these events, the Call Agent **MUST** use the NCS Line package digit (0-9,*,#,A,B,C,D,X) and digit related events (L, t) to request them. The Call Agent **MAY** request the processing of digit events in any manor allowed by NCS. For example, the endpoint may be instructed to collect digits according to a supplied Digit Map.

6.2.2 Digit Events over E&M

When an E&M PBX trunk is setup to use a start of dialing method of "immediate start" the Call Agent **SHOULD** take special precautions to insure that digits are not missed from the PBX. The PBX will start dialing after a short delay after going off-hook. This may occur before the Call Agent requests digits from the endpoint after being notified of the off-hook event. There are mechanisms allowed by NCS to guard against this. For example, the endpoint may be instructed to quarantine digits while in this state. This is accomplished by the use of the detectEvents parameter. Another option is to use an embedded request to instruct the endpoint to autonomously collect digits upon off-hook detection. See [NCS] for more information.

6.2.3 Local Tones

Though only a few local tones (MTA -> PBX) are required for analog trunking for PBX as indicated in Table 2, each physical interface SHOULD be capable of applying all requested NCS Line package tones towards the PBX. To maintain as much flexibility as possible and to support potential future PBX-like features, the endpoint MUST apply the requested tones (with noted exceptions below) as per the rules of NCS as long as the endpoint is physically capable of doing so.

6.2.3.1 Local Tones over E&M

Dial tone is not applied over an E&M physical interface. When either dial-tone (L/dl), stutter dial tone (L/sl) or message waiting indicator tone (L/mwi) is requested by the Call Agent to be applied over an E&M interface, the MTA MUST NOT apply the tone itself. Instead, the MTA MUST use the signal request to aid in detecting "no dial" occurrences. As such, the MTA MUST generate an operation complete event if digits are not detected in time just as it does when dial tone itself is applied (as long as the "keep alive" action is not used in the request). Note that this is simply one example of a timeout signal being stopped by the occurrence of an event. All NCS rules governing the application of a timeout signal MUST be followed.

All other local tones, when requested, are applied towards the PBX over an E&M interface.

6.2.4 Caller ID and VMWI

The Caller ID and VMWI NCS Line package signals apply only to LS/GS PBX trunk interfaces.

The call setup (PAT/sup) signal defined in the PAT package is used to deliver caller ID information; however, the Call Agent MAY alternatively use the Line package Caller ID signal to provide caller ID information. Though the PBX typically only expects to receive caller ID information during call setup, the Call Agent MAY use the Line package Caller ID signal to attempt to display caller ID when the PBX is off-hook (e.g., Caller ID with Call Waiting). To maintain as much flexibility as possible with the use of the NCS Line package the endpoint MUST honor such a request and attempt to deliver the caller ID information as defined in NCS.

The same is true of VMWI. Though the PBX typically does not expect to receive VMWI information, the Call Agent MAY use the Line package VMWI signal. To maintain as much flexibility as possible with the use of the NCS Line package the endpoint MUST honor such a request and attempt to deliver the VMWI information as defined in NCS.

6.2.5 Hook Events

For all physical interface types, the NCS Line package hook events (L/hd, L/hf, L/hu) are used to indicate hook state at the PBX.

For LS/GS, hook events are detected and generated as defined in NCS.

Similarly, for E&M, on-hook and off-hook events are generated when the corresponding signal is detected from the PBX. Based on timing, a flash-hook event may also be generated.

For DID battery reversal is considered to be an off-hook signal from the PBX. Likewise, the transition from reversed to normal battery is considered an on-hook signal. Battery removal is also considered to be an off-hook signal from the PBX. The transition from no battery to battery being detected is considered to be an on-hook signal. Based on the timing of the battery events, e.g., battery removal followed by battery restoration, a flash-hook event may also be signaled by the PBX. The endpoint MUST generate the corresponding NCS Line package hook events.

Note that a PBX uses an off-hook signal to block further calls from being initiated on the trunk.

For T1, in addition to the emulated on-hook and off-hook events, a red alarm condition indicates that no further calls may be processed; however, an off-hook event MUST NOT be generated when this condition occurs. Instead the endpoint MUST be taken out of service and an RSIP Forced MUST be sent to the Call Agent.

6.2.6 Open Signal Interval

For loop-start lines the L/osi NCS Line package signal is used as a trigger for the endpoint to perform a "timed disconnect release". For ground-start lines, the signal is used as a trigger for the endpoint to provide a "guard release" which has similar characteristics to the loop-start "timed disconnect release". This signal is defined in [GR 506] in general terms as an "open signal interval" for both loop-start and ground-start interfaces.

For all PBX trunks, the PAT/rel signal is used as a trigger for the PBX to release the call. For LS/GS the semantics are identical to the L/osi signal. In order to maintain the concept of a physical layer abstraction to the Call Agent and to provide the increased flexibility of the L/osi signal for LS/GS, the L/osi signal is further defined to be identical to the PAT/rel signal for E&M and DID physical interfaces which results in an on-hook from the endpoint. As such, the L/osi signal MAY be used by the CMS as an alternative for PAT/rel for all physical interface types.

For GS/LS the Call Agent MAY adjust the OSI interval using the L/osi signal parameterized with the "to" parameter, e.g., L/osi(to=800). For E&M and DID, however, the "to" parameter has no effect and, if provided, MUST be ignored.

6.2.7 Ring Requests

The ring NCS Line package signal requests only apply to LS/GS trunks.

The call setup (PAT/sup) signal defined in the PAT package is used as a trigger to seize the trunk by applying standard ringing; however, the Call Agent MAY alternatively use the Line package RG signal to provide ringing. Though the PBX typically only expects to receive standard ringing, the Call Agent MAY request other defined the Line package ring signals (R0 – R7, RS) to seize the trunk. To maintain as much flexibility as possible with the use of the NCS Line package the endpoint MUST honor such a request and attempt to seize the trunk using the defined ring signal.

6.2.8 T1 Trunk Signaling Requirements

T1 is a digital trunk interface. As such, the signaling between the MTA and PBX required to support one-way incoming, one-way outgoing and two-way PBX trunks is emulated using Channel Associated Signaling (CAS). The signaling between the MTA and Call Agent, however, remains unchanged. In other words, the fact that the physical interface is emulated digitally is of no consequence to the Call Agent.

Annex A Event Packages (Normative)

This section defines a set of event packages for the various types of endpoints currently defined by IPCablecom for embedded clients.

Each package defines a package name for the package and event codes and definitions for each of the events in the package. In the tables of events/signals for each package, there are five columns:

Code	The package unique event code used for the event/signal.
Description	A short description of the event/signal.
Event	A check mark appears in this column if the event can be Requested by the Call Agent. Alternatively, one or more of the following symbols may appear: "P" indicating that the event is persistent, "S" indicating that the event is an event-state that may be audited, "C" indicating that the event/signal may be detected/applied on a connection.
Signal	If nothing appears in this column for an event, then the event cannot be signaled on command by the Call Agent. Otherwise, the following symbols identify the type of event: "OO" On/Off signal. The signal is turned on until commanded by the Call Agent to turn it off, and vice versa. "TO" Timeout signal. The signal lasts for a given duration unless it is superseded by a new signal. Default time-out values are supplied. A value of zero indicates that the time-out period is infinite. The provisioning process may alter these default values. "BR" Brief signal. The event has a short, known duration.

Additional info Provides additional information about the event/signal, e.g., the default duration of TO signals.

Unless otherwise stated, all events are detected on endpoints. Likewise, unless otherwise stated, all signals are applied onto endpoints. When the application of a signal onto an endpoint results in the generation of audio, the audio is not forwarded onto any connection residing on the endpoint. However, when the signal is applied to a connection, the audio generated by will be forwarded onto the associated connection irrespective of the connection mode.

A.1 IPCablecom Analog Trunking for PBX Package

Package name: PAT

The codes listed in Table 3 below are used to identify events and signals for the "IPCablecom Analog Trunking for PBX" package for "analog access lines". This package provides missing functionality from the NCS Line package required to support analog trunking for PBX and, therefore, MUST be used in conjunction with the NCS Line package.

Table 3 – PAT Package Codes for Events and Signals

Code	Description	Event	Signal	Additional Info
ans	Call Answer		BR	
bl	Call Block		OO	
oc	Operation Complete	√	-	
of	Operation Failure	√	-	
rel	Release Call		BR	
sup(addr, ti, nu, na)	Call Setup		TO	Time-out = infinite

The definition of the individual events and signals are as follows:

Call answer (ans): A signal indicating that the far end has answered. For loop-start and ground-start PBX trunks a Reverse Loop Current Feed (RLCF) condition is applied as defined in [GR 506]. For E&M PBX trunks, an off-hook signal is applied which indicates that the call has been answered and that cut-through has been established.

When the call is answered at the PBX an off-hook event is generated as defined in the NCS Line package. This is applicable to all interface types except DID.

Call block (bl): Depending on the physical interface, this is either a battery removal or a steady off-hook signal typically applied to one-way outgoing trunks (PBX → endpoint), but MAY be applied to one-way incoming and two-way PBX trunks to indicate that no further calls will be accepted. Call block is enabled via the Call Agent by using either "bl" or "bl(+)". The blocked condition remains in effect until disabled via the Call Agent by using "bl(-)". As with other signals of this type, the call block state does not survive a reset.

In the case of DID, an off-hook is not applied towards the PBX. Instead, the endpoint is simply marked as "blocked" internally. Regardless of the physical interface or trunk type, subsequent call setup requests MUST be rejected using error code 513 – not equipped to generate signal. Note in this case that the error condition is not permanent. The Call Agent SHOULD correct the condition when it finds an endpoint unintentionally left in the "blocked" state. One way to detect such a condition before a call setup is attempted is to audit active signals on the endpoint.

Note that a PBX may also block a trunk by either going off-hook (LS/GS/E&M) or removing battery (DID). When the PBX goes off-hook to block a trunk, the off-hook event defined in the NCS Line package is generated.

Operation complete (oc): The operation complete event is generated when the gateway was asked to apply one or several signals of type TO on the endpoint, and one or more of those signals completed without being stopped by the detection of a requested event such as off-hook transition or dialed digit. The completion report may carry as a parameter the name of the signal that came to the end of its live time, as in:

O: PAT/oc (PAT/sup)

When the operation complete event is requested, it cannot be parameterized with any event parameters.

Note that when requested with the "sup" signal (out-pulsing – a TO event), the operation complete event will indicate when out-pulsing is complete.

Operation failure (of): In general, the operation failure event may be generated when the endpoint was asked to apply one or several signals of type TO on the endpoint, and one or more of those signals failed prior to timing out. The completion report may carry as a parameter the name of the signal that failed, as in:

O: PAT/of (PAT/sup)

When the operation failure event is requested, event parameters can not be specified.

Release call (rel): A "rel" signal sent by the Call Agent to the MTA is a request to release all of the resources associated with the telephony leg of the call. As a result of a "rel" signal, the MTA will respond with an "on-hook" event defined in the NCS Line package, whenever the resources have been released. Releasing resources associated with the telephony leg of the call does not affect existing connections (network legs). It's up to the Call Agent to send the appropriate delete connection commands in order to release any network connections to that endpoint.

For loop-start PBX trunks the "rel" signal results in a "timed disconnect release" which is identical to the OSI signal defined in NCS. For ground-start PBX trunks the "rel" signal results in a tip-ground release which is also considered to be an open signal interval

For E&M and DID PBX trunks the "rel" signal results in on on-hook being applied towards the PBX

The endpoint generates an "on-hook" event defined in the NCS Line package whenever a call is released as a result of an on-hook event from an originating end of a call (normal release) or due to an abnormal event that resulted in releasing the call. It is always up to the Call Agent to release the call (by sending the "rel" signal) for the terminating end of a call.

Following are two scenarios to demonstrate the use of the "rel" signal.

PBX goes on-hook first: when the PBX goes on-hook, the on-hook event is generated and is typically notified to the Call Agent. The Call Agent will respond at some point in time with the "rel" signal. This signal has no affect in

this case for LS/GS trunks since the call has already been released. For E&M/DID, however, the endpoint goes on-hook.

Network goes on-hook first: when the network side goes on-hook, the CMS will respond at some point in time with the "rel" signal. The endpoint will provide the signal as defined above towards the PBX. Some time later the PBX will go on-hook. The on-hook is detected by the endpoint and is processed accordingly.

Call Setup (sup(address, time, number, name)): This signal is used for incoming call setup (endpoint to PBX). An "off-hook" event as defined in the NCS Line package is used to indicate when an outgoing call arrives (corresponding to the outgoing off-hook event).

On an incoming trunk, the "sup" signal is used to seize a trunk and possibly out-pulse digits and/or caller ID information. For LS/GS trunks standard ringing is applied to seize the trunk.

Although a time-out signal, call setup time-out **MUST** be infinite. The endpoint **MUST** generate either a PAT/oc (for success) or PAT/of (for failure) event to signify its completion. The PAT/oc event **MUST** occur upon successful completion of out-pulsing of the last stage of information, otherwise PAT/of event **MUST** occur. The "sup" signal is parameterized with the following comma separated list of parameters sup(address, time, number, name). As shown in Table 4 below, depending on the physical interface, some of the parameters are either optional or ignored when provided. In any case, when these parameters are missing from the request each of the commas will always be included.

Table 4 – Call Setup Parameters

Interface Type	Address	Time	Number	Name
LS or GS	Ignored	Optional	Optional	Optional
E&M or DID	Mandatory	Ignored	Optional	Ignored

The four parameters of the "sup" signal are defined below:

- The **address** parameter is coded as an ASCII character string of decimal digits that identify the destination number. White spaces are permitted if the string is quoted, however they will be ignored. For LS/GS trunks the address parameter, if provided, **MUST** be ignored. For E&M/DID trunks this parameter **MUST** be present. In this case the command containing the "sup" signal **MUST** be rejected if the address parameter is not present. To maintain the physical layer abstraction, it is **RECOMMENDED** that the Call Agent always provide the address parameter.
- The **time** parameter contains the calling timestamp and is coded as "MM/DD/HH/MM", where the first MM is a two-digit value for Month between 01 and 12, DD is a two-digit value for Day between 1 and 31, and Hour and Minute are two-digit values coded according to military local time, e.g., 00 is midnight, 01 is 1 a.m., and 13 is 1 p.m. For E&M/DID trunks the time parameter, if provided, **MUST** be ignored.
- The **number** parameter is coded as an ASCII character string of decimal digits that identify the calling line number. White spaces are permitted if the string is quoted, however they will be ignored.
- The **name** parameter is coded as a string of ASCII characters that identify the calling line name. White spaces, commas, and parentheses are permitted if the string is quoted. For E&M/DID trunks the name parameter, if provided, **MUST** be ignored.

See [TR-NWT-001188] and [TR-NWT-000031] for more information on the caller ID parameters of the "sup" signal.

As shown above, caller ID information **MAY** be supplied to the endpoint via the "sup" signal. Only the fields relevant to the physical interface are used. The rest are ignored. For LS/GS trunks, full caller ID information may be delivered. For E&M and DID trunks, however, only the caller ID number is delivered as shown in Table 6.

When the "sup" signal is requested and Caller ID information is not present, the operation complete event is generated after the last destination address digit is out-pulsed as described above. If the destination address parameter is either excluded from the "sup" signal request or ignored, then the operation complete event is generated after the PBX goes off-hook. This is applicable only to LS/GS trunks. For E&M/DID the destination address **MUST** be provided.

The following table shows some interactions between the MTA and the PBX for single stage out-pulsing applications (i.e., "sup" signal with <addr> field present in command only).

Table 5 – PBX Sequencing during Call Setup (Single Stage)

Interface Type	Setup	Interactions
Wink start	sup(address, , ,)	MTA off-hook → PBX MTA ← wink PBX MTA address → PBX
Immediate start	sup(address, , ,)	MTA off-hook → PBX MTA address → PBX

An example Call Setup signal using DTMF digits is as follows:

PAT/sup(5551234, , ,)

Table 6 shows an example of multi-stage signaling (i.e., both caller ID number and address parameters present in command). There are many variations of caller ID delivery to a PBX and most are specific to the PBX itself. The example in the Table 6 is only one variation. The MTA MAY need to be configured with the caller ID delivery method if it supports more than one.

Table 6 – PBX Sequencing during Call Setup (Multi-Stage)

Setup	Interactions
sup(address, , number,)	MTA off-hook → PBX MTA ← wink PBX MTA number → PBX MTA address → PBX

In either case the off-hook event defined in the NCS Line package is an indication of off-hook from the far end (the other end answered).

Annex B Sample Call Flows (Informative)

Sample call flows are provided below to demonstrate call setup, call teardown, and call block/release. In order to show both variations of call setup – PBX initiated and network initiated – the call is originated on one PBX and terminated on another. The same is true of the call teardown example. The call, prior to teardown, is setup between two separate PBX’s which in essence shows both variations of call teardown – PBX initiated and network initiated.

For simplicity, only one Call Agent is used in all call flow examples below since intra Call Agent communications is beyond the scope of this specification.

B.1 CALL SETUP Call Flow Example

In the following example call flow, the call is originated on PBX-o which uses either a one-way outgoing or two-way PBX trunk connected to an endpoint on either an MTA or Media Gateway and is denoted as EP-o. The call is terminated on PBX-t which is connected to another MTA or Media Gateway using either a one-way incoming or two-way PBX trunk and is denoted as EP-t.

#	PBX-o	EP-o	CA	EP-t	PBX-t
1	off-hook	->			
2		NTFY (hd)	->		
3			<- 200		
4			<- RQNT (dl, digits)		
5		200	->		
6	<- start dial				
7	digits	->			
8		NTFY (digits)	->		
9			<- 200		
10			<- RQNT (rt, hu)		
11		200	->		
12	<- ring back				
13			<- CRCX		
14		200 (sdp-o)	->		
15			RQNT (sup, oc, of)	->	
16				<- 200	
17				call setup	->
18					<- setup ack
19				address/cid	->
20				<- NTFY (oc (sup))	
21				200	->
22			RQNT (hd)	->	
23				<- 200	
24					<- off-hook
25				<- NTFY (hd)	
26				200	->
27			RQNT (hu)	->	
28				<- 200	
29			CRCX (sdp-o)	->	
30				<- 200 (sdp-t)	
31			<- MDCX (sdp-t)		
32		200	->		
33			<- RQNT (ans)		
34		200	->		
35	<- answer sup.				

Step 1:

A user behind PBX-o goes off-hook and dials "9", for example, to seize an outside line. PBX-o signals off-hook towards EP-o to seize an available trunk.

Step 2:

The off-hook event is notified to the Call Agent.

```
NTFY 6 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 36
O: hd
```

Step 3:

The Call Agent acknowledges the NTFY.

```
200 6 OK
```

Step 4:

The Call Agent sends an RQNT to play dial tone and request digits according to the supplied digit map.

```
RQNT 41 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 37
D: (xxxxxxxx|x.[T#])
R: hu, [0-9*#T] (D)
S: dl
```

Step 5:

EP-o acknowledges the RQNT.

```
200 41 OK
```

Step 6:

EP-o applies the start of dialing signal. For LS and GS dial tone is applied. For E&M, start of dialing is signaled according to the start of dialing method configured. For wink start a 200 ms off-hook wink is applied towards the PBX. For delay start a 140 ms off-hook signal is generated. The dial tone requested in step 4 above is not applied, but a timer is set at this point based on the configuration for default dial tone timeout. An "operation complete" event is generated if digits are not detected in time.

Step 7:

EP-o collects the digits generated by PBX-o.

Step 8:

The digits collected in step 7 trigger a match in the digit map. EP-o sends a NTFY to the Call Agent.

```
NTFY 7 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 37
O: 5,5,5,1,2,1,2
```

Step 9:

The Call Agent acknowledges the NTFY.

```
200 7 OK
```

Step 10:

The Call Agent sends an RQNT to play ring back tone and requests notification of on-hook.

```
RQNT 42 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 38
R: hu
S: rt
```

Step 11:

EP-o acknowledges the RQNT.

```
200 42 OK
```


Step 12:

EP-o applies ring back tone towards PBX-o.

Step 13:

The Call Agent creates a connection on EP-o.

```
CRCX 43 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
C: 51005E4E0003A9ED1700
M: inactive
L: mp:20, a:PCMU
```

Step 14:

EP-o creates the connection, acknowledges the CRCX and returns its SDP.

```
200 43 OK
I: 3

<sdp-o>
```

Step 15:

The Call Agent requests call setup on EP-t by sending an RQNT with PAT/sup.

```
RQNT 44 aaln/1@ep-t.whatever.net MGCP 1.0 NCS 1.0
X: 39
R: hd, PAT/oc, PAT/of
S: PAT/sup(5551212, 02/13/06/59, 5551313, "John Doe")
```

Step 16:

EP-t acknowledges the RQNT.

```
200 44 OK
```

Step 17:

EP-t applies the call setup signal towards PBX-t to seize the trunk. For LS and GS standard ringing is applied to seize the trunk. For E&M and DID EP-t signals off-hook to seize the trunk.

Step 18:

EP-t receives a setup acknowledgment from PBX-t. This signal only applies to E&M and DID trunks configured with a start of dialing method of wink or delay. For wink start a 200 ms off-hook wink is signaled from PBX-t. For delay start a 140 ms off-hook signal is generated.

If EP-t does not receive the expected setup acknowledgment in time an "operation failure" event is generated against the PAT/sup signal.

Step 19:

EP-t sends caller ID and/or address information provided via the PAT/sup signal request. For LS and GS lines, full caller ID information is delivered via FSK signaling after the first ring cycle. The address information is ignored. For E&M and DID the address information and caller ID number is delivered to PBX-t. The rest is ignored. Furthermore, only the last "N" digits of the address are out-pulsed towards the PBX where N is equal to the configured value of the "maximum out-pulse dial string". So, for example, if the maximum out-pulse dial string is set to four, then only digits "1, 2, 1, 2" are out-pulsed in this example.

Step 20:

Upon completion of caller ID and/or address delivery the EP-t generates an "operation complete" event for the PAT/sup signal and sends a NTFY to the Call Agent.

```
NTFY 8 aaln/1@ep-t.whatever.net MGCP 1.0 NCS 1.0
X: 39
O: PAT/oc (PAT/sup)
```

Step 21:

The Call Agent acknowledges the NTFY.

```
200 8 OK
```

Step 22:

The Call Agent sends an RQNT to request off-hook.

```
RQNT 45 aaln/1@ep-t.whatever.net MGCP 1.0 NCS 1.0
X: 3A
R: hd
```

Step 23:

EP-t acknowledges the RQNT.

```
200 45 OK
```

Step 24:

The far end answers which results in PBX-t signaling off-hook. For LS, GS and DID PBX-t applies reverse battery to signal that the far end answered. For E&M PBX-t signals off-hook.

Step 25:

EP-t notifies the off-hook event.

```
NTFY 9 aaln/1@ep-t.whatever.net MGCP 1.0 NCS 1.0
X: 3A
O: hd
```

Step 26:

The Call Agent acknowledges the NTFY.

```
200 9 OK
```

Step 27:

The Call Agent sends an RQNT to request on-hook.

```
RQNT 46 aaln/1@ep-t.whatever.net MGCP 1.0 NCS 1.0
X: 3B
R: hu
```

Step 28:

EP-t acknowledges the RQNT.

```
200 46 OK
```

Step 29:

The Call Agent creates a connection on EP-t which includes sdp-o.

```
CRCX 47 aaln/1@ep-t.whatever.net MGCP 1.0 NCS 1.0
C: 51005E4E0003A9ED1700
M: sendrecv
L: mp:20, a:PCMU
```

```
<sdp-o>
```

Step 30:

EP-t acknowledges the CRCX and returns its SDP.

```
200 47 OK
I: 4
```

```
<sdp-t>
```

Step 31:

The Call Agent modifies the connection on EP-o to send-recv.

```
MDCX 48 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
C: 51005E4E0003A9ED1700
I: 3
M: sendrecv
```

Step: 31:

EP-o acknowledges the MDCX.

```
200 48 OK
```

Step 32:

The Call Agent sends an RQNT to EP-o to apply answer supervision.

```
RQNT 49 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 3C
R: hu
S: PAT/ans
```

Step 33:

EP-o acknowledges the RQNT.

```
200 49 OK
```

Step 34:

EP-o applies answer supervision towards PBX-o. For LS and GS EP-o applies reverse battery. For E&M EP-o applies off-hook. At this point the call is fully established.

B.2 CALL TEARDOWN Call Flow Example

In the following example call flow, PBX-o is connected to either an MTA or Media Gateway via a one-way or two-way PBX trunk. The endpoint is denoted as EP-o. PBX-t is connected to either an MTA or Media Gateway via a one-way or two-way PBX trunk. The endpoint is denoted as EP-t. A call is fully established between PBX-o and PBX-t.

#	PBX-o	EP-o	CA	EP-t	PBX-t
1	on-hook	->			
2		NTFY (hu)	->		
3		200	->		
4		<-	DLCX		
5		250	->		
6		<-	RQNT (rel)		
7		200	->		
8	<-	release			
9			RQNT (rel)	->	
10			<-	200	
11				release	->
12				<-	on-hook
13			<-	NTFY (hu)	
14			200	->	
15			DLCX	->	
16			<-	250	
17			RQNT (hd)	->	
18			<-	200	

Step 1:

PBX-o signals on-hook to EP-o. For DID normal battery is applied from PBX-o to signal on-hook.

Step 2:

EP-o notifies the on-hook event.

```
NTFY 10 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 3C
O: hu
```

Step 3:

The Call Agent acknowledges the NTFY.

```
200 10 OK
```

Step 4:

The Call Agent deletes the connection on EP-o.

```
DLCX 50 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
C: 51005E4E0003A9ED1700
I: 3
```

Step 5:

EP-o acknowledges the DLCX.

```
250 50 OK
P: PS=110, OS=110, PR=110, OR=110, PL=0, JI=0, LA=0, PC/RCS=110, PC/ROS=110,
PC/RPL=0, PC/RJI=0
```

Step 6:

The Call Agents sends an RQNT to EP-o to release the resources to PBX-o.

```
RQNT 51 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 3D
R: hd
S: PAT/rel
```

Note that the Call Agent may also use S: osi to signal call release.

Step 7:

EP-o acknowledges the RQNT.

```
200 51 OK
```

Step 8:

EP-o signals a release towards PBX-o to allow the PBX to release internal resources. For LS and GS normal battery is applied. For E&M and DID an on-hook signal is applied.

Step 9:

The Call Agent sends an RQNT to EP-t to release the call.

```
RQNT 52 aaln/1@ep-t.whatever.net MGCP 1.0 NCS 1.0
X: 3E
R: hu
S: PAT/rel
```

Note that the Call agent may also use S: osi to signal call release.

Step 10:

EP-t acknowledges the RQNT.

```
200 52 OK
```

Step 11:

EP-t signals a release towards PBX-t to indicate that the far end has disconnected. For LS and GS EP-t applies forward disconnect (OSI) for a default duration of 900 ms. For E&M and DID an on-hook signal is applied.

Step 12:

PBX-t signals on-hook. For DID normal battery is applied from PBX-t.

Step 13:

EP-t notifies the on-hook event to the Call Agent.

```
NTFY 11 aaln/1@ep-t.whatever.net MGCP 1.0 NCS 1.0
X: 3E
O: hu
```

Step 14:

The Call Agent acknowledges the NTFY.

```
200 11 OK
```

Step 15:

The Call Agent deletes the connection on EP-t.

```
DLCX 53 aaln/1@ep-t.whatever.net MGCP 1.0 NCS 1.0
C: 51005E4E0003A9ED1700
I: 4
```

Step 16:

EP-o acknowledges the DLCX.

```
250 53 OK
P: PS=110, OS=110, PR=110, OR=110, PL=0, JI=0, LA=0, PC/RCS=110, PC/ROS=110,
PC/RPL=0, PC/RJI=0
```

Step 17:

The Call Agent sends an RQNT for off-hook.

Step 18:

```
RQNT 54 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 3F
R: hd
```

Step 19:

EP-t acknowledges the RQNT.

```
200 54 OK
```

B.3 CALL BLOCK/RELEASE Call Flow Example – Network Initiated

In the following example call flow, the PBX trunk between PBX-o and EP-o is blocked then later released by the Call Agent. The endpoint is on-hook and idle prior to being blocked. The call flow also shows an attempt by the Call Agent to setup a new call on EP-o while in the blocked state.

#	PBX-o	EP-o	CA	EP-t	PBX-t
1			<- RQNT (bl (+))		
2		200	->		
3	<-	call block			
4			<- RQNT (sup, oc, of)		
5		513	->		
6			<- AUEP (signals)		
7		200 (S:bl (+))	->		
8			<- RQNT (bl (-))		
9		200	->		
10	<-	call release			

Step 1:

The Call Agent sends an RQNT to EP-o to block PBX-o from initiating further calls on the trunk.

```
RQNT 55 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 40
R: hd
S: PAT/bl (+)
```

Step 2:

EP-o acknowledges the RQNT.

```
200 55 OK
```

Step 3:

EP-o signals call block towards PBX-o. For LS and GS battery is removed by EP-o. For E&M a steady off-hook signal is applied. For DID the internal state of EP-o is set to "blocked" only.

Step 4:

The Call Agents attempts call setup by sending an RQNT with the PAT/sup signal.

```
RQNT 56 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 41
R: hd, PAT/oc, PAT/of
S: PAT/sup(5551212, 02/13/06/59, 5551313, "John Doe")
```

Step 5:

EP-o sends error code 513 to the Call Agent since the call setup can not be executed at this time.

```
513 56 Not Equipped to Apply Signal (Endpoint Blocked)
```

Step 6:

The Call Agent sends an EUEP to EP-o to audit active signals.

```
AUEP 57 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
F: S
```

Step 7:

EP-o responds to the AUEP message indicating that the endpoint is blocked.

```
200 57 OK
S: PAT/bl (+)
```

Step 8:

The Call Agents sends an RQNT to EP-o to release the blocked condition.

```
RQNT 58 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 42
```

R: hd
S: PAT/bl (-)

Step 9:

EP-o acknowledges the RQNT.

200 58 OK

Step 10:

EP-o releases the blocked condition. For LS and GS EP-o applies battery. For E&M EP-o goes on-hook. For DID the internal state is changed to normal (from blocked).

B.4 CALL BLOCK/RELEASE Call Flow Example – PBX Initiated

In the following example call flow, the PBX trunk between PBX-o and EP-o is blocked then later released by the PBX. The endpoint is on-hook and idle prior to being blocked. The call flow also shows an attempt by the Call Agent to setup a new call on EP-o while in the blocked state.

```

-----
| # | PBX-o | EP-o | CA | EP-t | PBX-t | | |
|==|=====|=====|=====|=====|=====|
| 1 | off-hook | -> | | | | |
| 2 | | NTFY (hd) | -> | | | |
| 3 | | | <- | 200 | | | |
| 4 | | | <- | RQNT (dl,digits) | | | |
| 5 | | | 200 | -> | | | |
| 6 | | <- | start dial | | | |
| 7 | (no digits) | -> | | | | |
| 8 | | NTFY (oc (dl)) | -> | | | |
| 9 | | | <- | 200 | | | |
|10 | | | <- | RQNT (hu) | | | |
|11 | | | 200 | -> | | | |
|12 | | | <- | RQNT (sup,oc,of) | | | |
|13 | | | 401 | -> | | | |
|14 | | | <- | RQNT (hu) | | | |
|15 | | | 200 | -> | | | |
|---|-----|-----|-----|-----|-----|
|16 | on-hook | -> | | | | |
|17 | | NTFY (hu) | -> | | | |
|18 | | | <- | 200 | | | |
|19 | | | <- | RQNT (hd) | | | |
|20 | | | 200 | -> | | | |

```

Step 1:

PBX-o signals off-hook to block the trunk from further calls. For DID battery is removed by PBX-o.

Step 2:

The off-hook event is notified to the Call Agent.

NTFY 12 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 42
O: hd

Step 3:

The Call Agent acknowledges the NTFY.

200 12 OK

Step 4:

The Call Agent sends an RQNT to play dial tone and request digits according to the supplied digit map.

```
RQNT 59 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 43
D: (xxxxxxxx|x.[T#])
R: hu, [0-9*#T](D)
S: dl
```

Step 5:

EP-o acknowledges the RQNT.

```
200 59 OK
```

Step 6:

EP-o applies the start of dialing signal. For LS and GS dial tone is applied. For E&M, start of dialing is signaled according to the start of dialing method configured. For wink start a 200 ms off-hook wink is applied towards the PBX. For delay start a 140 ms off-hook signal is generated. The dial tone requested in step 4 above is not applied, but a timer is set at this point based on the configuration for default dial tone timeout. An "operation complete" event is generated if digits are not detected in time.

Step 7:

No digits are detected in time as described in Step 6.

Step 8:

EP-o sends a NTFY to the Call Agent indicating that dial tone timed out.

```
NTFY 13 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 43
O: oc(dl)
```

Step 9:

The Call Agent acknowledges the NTFY.

```
200 13 OK
```

Step 10:

The Call Agent sends an RQNT to request notification of on-hook. At this point the endpoint is blocked from the perspective of the Call Agent.

```
RQNT 60 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 44
R: hu
```

Step 11:

EP-o acknowledges the RQNT.

```
200 60 OK
```

Step 12:

The Call Agents attempts call setup by sending an RQNT with the PAT/sup signal.

```
RQNT 61 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 45
R: PAT/oc, PAT/of
S: PAT/sup(5551212, 02/13/06/59, 5551313, "John Doe")
```

Step 13:

EP-o sends error code 401 to the Call Agent since the call setup can not be executed at this time.

```
401 61 Phone Already Off-hook
```

Step 14:

The Call Agent sends an RQNT to once again request notification of on-hook.


```
RQNT 62 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 46
R: hu
```

Step 15:

EP-o acknowledges the RQNT.

```
200 62 OK
```

Step 16:

PBX-o releases the blocked condition by signaling on-hook. For DID battery is restored by PBX-o.

Step 17:

EP-o sends a NTFY to the Call Agent indicating that PBX-o has gone on-hook.

```
NTFY 14 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 46
O: hu
```

Step 18:

The Call Agent acknowledges the NTFY.

```
200 14 OK
```

Step 19:

The Call Agent sends an RQNT to request notification of off-hook.

```
RQNT 63 aaln/1@ep-o.whatever.net MGCP 1.0 NCS 1.0
X: 47
R: hu
```

Step 15:

EP-o acknowledges the RQNT.

```
200 63 OK
```

