



***Society of Cable
Telecommunications
Engineers***

**ENGINEERING COMMITTEE
HFC Management Subcommittee**

AMERICAN NATIONAL STANDARD

ANSI/SCTE 85-3 2009

**HMS Inside Plant
Management Information Base (MIB)
SCTE-HMS-HE-OPTICAL-AMPLIFIER-MIB**

NOTICE

The Society of Cable Telecommunications Engineers (SCTE) Standards are intended to serve the public interest by providing specifications, test methods and procedures that promote uniformity of product, interchangeability and ultimately the long term reliability of broadband communications facilities. These documents shall not in any way preclude any member or non-member of SCTE from manufacturing or selling products not conforming to such documents, nor shall the existence of such standards preclude their voluntary use by those other than SCTE members, whether used domestically or internationally.

SCTE assumes no obligations or liability whatsoever to any party who may adopt the Standards. Such adopting party assumes all risks associated with adoption of these Standards, and accepts full responsibility for any damage and/or claims arising from the adoption of such Standards.

Attention is called to the possibility that implementation of this standard may require the use of subject matter covered by patent rights. By publication of this standard, no position is taken with respect to the existence or validity of any patent rights in connection therewith. SCTE shall not be responsible for identifying patents for which a license may be required or for conducting inquiries into the legal validity or scope of those patents that are brought to its attention.

Patent holders who believe that they hold patents which are essential to the implementation of this standard have been requested to provide information about those patents and any related licensing terms and conditions. Any such declarations made before or after publication of this document are available on the SCTE web site at <http://www.scte.org>.

All Rights Reserved

© Society of Cable Telecommunications Engineers, Inc. 2009
140 Philips Road
Exton, PA 19341

TABLE OF CONTENTS

1.0	SCOPE	1
2.0	COPYRIGHT	1
3.0	NORMATIVE REFERENCES	1
4.0	INFORMATIVE REFERENCES	1
5.0	TERMS AND DEFINITIONS	1
6.0	REQUIREMENTS.....	1

1.0 SCOPE

This document provides MIB definitions for HMS optical amplifiers present in the headend (or indoor) and supported by a SNMP agent

2.0 COPYRIGHT

The MIB definition found in this document may be incorporated directly in products without further permission from the copyright owner, SCTE.

3.0 NORMATIVE REFERENCES

IETF RFC 1907 SNMPv2-MIB

IETF RFC 2578 SNMPv2-SMI

IETF RFC 2579 SNMPv2-TC

IETF RFC 2580 SNMPv2-CONF

IETF RFC 2737 ENTITY-MIB

SCTE 36 SCTE-ROOT

SCTE 37 SCTE-HMS-ROOTS

SCTE 38-11 SCTE-HMS-HEADENDIDENT-MIB

4.0 INFORMATIVE REFERENCES

None

5.0 TERMS AND DEFINITIONS

This document defines the following terms:

Management Information Base (MIB): the specification of information in a manner that allows standard access through a network management protocol.

6.0 REQUIREMENTS

This section defines the mandatory syntax of the SCTE-HMS-HE-OPTICAL-AMPLIFIER-MIB. It follows the IETF Simple Network Management Protocol (SNMP for defining managed objects.

The syntax is given below.

SCTE-HMS-HE-OPTICAL-AMPLIFIER-MIB DEFINITIONS ::= BEGIN

IMPORTS

MODULE-IDENTITY, OBJECT-TYPE, Unsigned32
FROM SNMPv2-SMI
MODULE-COMPLIANCE, OBJECT-GROUP
FROM SNMPv2-CONF
entPhysicalIndex
FROM ENTITY-MIB
HeOnOffStatus, HeOnOffControl, HeLaserType,
HeTenthCentigrade, HeTenthdB, HeTenthdBm, HeMilliAmp
FROM SCTE-HMS-HEADENDIDENT-MIB
heOpticalAmplifierGroup
FROM SCTE-HMS-HE-OPTICS-MIB;

heOpticalAmplifierMIB MODULE-IDENTITY

LAST-UPDATED "200312100000Z" -- December 10, 2003
ORGANIZATION "SCTE HMS Working Group"
CONTACT-INFO
"SCTE HMS Subcommittee, Chairman
mailto: standards@scte.org"

DESCRIPTION

"The MIB module is for representing optical amplifiers
present in the headend (or indoor) and are supported by a
SNMP agent."

::= { heOpticalAmplifierGroup 1 }

heOpAmpMIBObjects OBJECT IDENTIFIER ::= { heOpticalAmplifierMIB 1 }

-- The Optical Amplifier Unit Table

heOpAmpUnitTable OBJECT-TYPE

SYNTAX SEQUENCE OF HeOpAmpUnitEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION

"A table containing information about headend (or indoor)
fiber optic amplifiers. These amplifiers could be plug-in
modules for a chassis, stand-alone pizza-box units etc."

::= { heOpAmpMIBObjects 1 }

heOpAmpUnitEntry OBJECT-TYPE

SYNTAX HeOpAmpUnitEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION

"Information about each Fiber Optic amplifier in
the subsystem."

INDEX { entPhysicalIndex }

::= { heOpAmpUnitTable 1 }

HeOpAmpUnitEntry ::= SEQUENCE

```
{
  heOpAmpUnitOutputStatus  HeOnOffStatus,
  heOpAmpUnitOnOffControl  HeOnOffControl
}
```

heOpAmpUnitOutputStatus OBJECT-TYPE

SYNTAX HeOnOffStatus

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The output status of the amplifier.

If all the outputs of the amplifier are off then the variable value shall be off(1), else the value shall be on(2).

This object must provide for the alarm management capabilities with a corresponding entry in the discretePropertyTable of SCTE-HMS-PROPERTY-MIB (HMS026).

An alarm shall be recorded as an entry in the currentAlarmTable of SCTE-HMS-PROPERTY-MIB (HMS026).

A log record shall be added as an entry in the heCommonLogTable.

An heCommonAlarmEvent notification shall be sent."

::= { heOpAmpUnitEntry 1 }

heOpAmpUnitOnOffControl OBJECT-TYPE

SYNTAX HeOnOffControl

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This variable controls the output status of the amplifier.

Setting this variable to off(1) will cause all the amplifier outputs to be shut off.

Setting this variable to on(2) will cause all the amplifier outputs to be turned on.

A value meaningless(3) will be implemented by the variables that represent a switch with write-only access. A GET request for the value of the write-only variable shall return a value meaningless(3).

A SET request with a value meaningless(3) for the variable with write access shall have no effect and no exception is generated.

A value may be used by the variables with both read-write and write-only access.

The variables with read-only access shall be defined with

the textual convention HeOnOffStatus."

::= { heOpAmpUnitEntry 2 }

-- The Optical Amplifier Input Table
heOpAmpInputTable OBJECT-TYPE
SYNTAX SEQUENCE OF HeOpAmpInputEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"A table containing information related to input Parameters
in headend (or indoor) fiber optic amplifiers. These
amplifiers could be plug-in modules for a chassis,
stand-alone pizza-box units etc."
::= { heOpAmpMIBObjects 2 }

heOpAmpInputEntry OBJECT-TYPE
SYNTAX HeOpAmpInputEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"Information about each Fiber Optic amplifier input in
the subsystem."
INDEX { entPhysicalIndex, heOpAmpInputIndex }
::= { heOpAmpInputTable 1 }

HeOpAmpInputEntry ::= SEQUENCE
{
heOpAmpInputIndex Unsigned32,
heOpAmpInputPower HeTenthdBm
}

heOpAmpInputIndex OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"An arbitrary value which uniquely identifies
the amplifier input."
::= { heOpAmpInputEntry 1 }

heOpAmpInputPower OBJECT-TYPE
SYNTAX HeTenthdBm
UNITS "0.1 dBm"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Optical input power.
This object must provide for the alarm management capabilities
with a corresponding entry in the propertyTable of
SCTE-HMS-PROPERTY-MIB (HMS026).

An alarm shall be recorded as an entry in the currentAlarmTable
of SCTE-HMS-PROPERTY-MIB (HMS026).

A log record shall be added as an entry in the heCommonLogTable.

An heCommonAlarmEvent notification shall be sent."

::= { heOpAmpInputEntry 2 }

-- The Optical Amplifier Laser Table
heOpAmpLaserTable OBJECT-TYPE
SYNTAX SEQUENCE OF HeOpAmpLaserEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"A table containing information about amplifier laser(s)."
::= { heOpAmpMIBObjects 3 }

heOpAmpLaserEntry OBJECT-TYPE
SYNTAX HeOpAmpLaserEntry
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"A list of information about each laser in
the particular amplifier."
INDEX { entPhysicalIndex, heOpAmpLaserIndex }
::= { heOpAmpLaserTable 1 }

HeOpAmpLaserEntry ::= SEQUENCE
{
heOpAmpLaserIndex Unsigned32,
heOpAmpLaserTemp HeTenthCentigrade,
heOpAmpLaserBiasCurrent HeMilliAmp,
heOpAmpLaserOutputPower HeTenthdBm,
heOpAmpLaserTECCurrent HeMilliAmp,
heOpAmpLaserType HeLaserType
}

heOpAmpLaserIndex OBJECT-TYPE
SYNTAX Unsigned32
MAX-ACCESS not-accessible
STATUS current
DESCRIPTION
"An arbitrary value which uniquely identifies the laser."
::= { heOpAmpLaserEntry 1 }

heOpAmpLaserTemp OBJECT-TYPE
SYNTAX HeTenthCentigrade
UNITS "0.1 degrees Celsius"
MAX-ACCESS read-only
STATUS current
DESCRIPTION
"Temperature of the amplifier laser.

This object must provide for the alarm management capabilities with a corresponding entry in the propertyTable of SCTE-HMS-PROPERTY-MIB (HMS026).

An alarm shall be recorded as an entry in the currentAlarmTable of SCTE-HMS-PROPERTY-MIB (HMS026).

A log record shall be added as an entry in the heCommonLogTable.

An heCommonAlarmEvent notification shall be sent."

::= { heOpAmpLaserEntry 2 }

heOpAmpLaserBiasCurrent OBJECT-TYPE

SYNTAX HeMilliAmp

UNITS "1.0 mA"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"Amplifier laser bias current in mA.

This object must provide for the alarm management capabilities with a corresponding entry in the propertyTable of SCTE-HMS-PROPERTY-MIB (HMS026).

An alarm shall be recorded as an entry in the currentAlarmTable of SCTE-HMS-PROPERTY-MIB (HMS026).

A log record shall be added as an entry in the heCommonLogTable.

An heCommonAlarmEvent notification shall be sent."

::= { heOpAmpLaserEntry 3 }

heOpAmpLaserOutputPower OBJECT-TYPE

SYNTAX HeTenthdBm

UNITS "0.1 dBm"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The laser output power.

This object must provide for the alarm management capabilities with a corresponding entry in the propertyTable of SCTE-HMS-PROPERTY-MIB (HMS026).

An alarm shall be recorded as an entry in the currentAlarmTable of SCTE-HMS-PROPERTY-MIB (HMS026).

A log record shall be added as an entry in the heCommonLogTable.

An heCommonAlarmEvent notification shall be sent."

::= { heOpAmpLaserEntry 4 }

heOpAmpLaserTECCurrent OBJECT-TYPE

SYNTAX HeMilliAmp

```

UNITS      "1.0 mA"
MAX-ACCESS read-only
STATUS     current
DESCRIPTION
    "Laser Thermo Electric Cooler current.
    This object must provide for the alarm management capabilities
    with a corresponding entry in the propertyTable of
    SCTE-HMS-PROPERTY-MIB (HMS026).

    An alarm shall be recorded as an entry in the currentAlarmTable
    of SCTE-HMS-PROPERTY-MIB (HMS026).

    A log record shall be added as an entry in the heCommonLogTable.

    An heCommonAlarmEvent notification shall be sent."
 ::= { heOpAmpLaserEntry 5 }

heOpAmpLaserType OBJECT-TYPE
SYNTAX     HeLaserType
MAX-ACCESS read-only
STATUS     current
DESCRIPTION
    "Laser type."
 ::= { heOpAmpLaserEntry 6 }

--      The Optical Amplifier Output Table
heOpAmpOutputTable OBJECT-TYPE
SYNTAX     SEQUENCE OF HeOpAmpOutputEntry
MAX-ACCESS not-accessible
STATUS     current
DESCRIPTION
    "A table containing information about amplifier's outputs."
 ::= { heOpAmpMIBObjects 4 }

heOpAmpOutputEntry OBJECT-TYPE
SYNTAX     HeOpAmpOutputEntry
MAX-ACCESS not-accessible
STATUS     current
DESCRIPTION
    "A list of information about each output in
    the particular amplifier."
INDEX { entPhysicalIndex, heOpAmpOutputIndex }
 ::= { heOpAmpOutputTable 1 }

HeOpAmpOutputEntry ::= SEQUENCE
{
    heOpAmpOutputIndex      Unsigned32,
    heOpAmpSetOpticalOutputPower HeTenthdBm,
    heOpAmpGainPerWavelength HeTenthdB,
    heOpAmpOutputPower      HeTenthdBm,
    heOpAmpOutputGainType   INTEGER
}

```

heOpAmpOutputIndex OBJECT-TYPE

SYNTAX Unsigned32

MAX-ACCESS not-accessible

STATUS current

DESCRIPTION

"An arbitrary value which uniquely identifies the output."

::= { heOpAmpOutputEntry 1 }

heOpAmpSetOpticalOutputPower OBJECT-TYPE

SYNTAX HeTenthdBm

UNITS "0.1 dBm"

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Set Amplifier Optical Output Power. The setting of this value has no effect unless the heOpAmpOutputGainType is set to constantPower(1)"

::= { heOpAmpOutputEntry 2 }

heOpAmpGainPerWavelength OBJECT-TYPE

SYNTAX HeTenthdB

UNITS "0.1 dBm"

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Controls constant gain per wavelength. The setting of this value has no effect unless the heOpAmpOutputGainType is set to constantGain(2)"

::= { heOpAmpOutputEntry 3 }

heOpAmpOutputPower OBJECT-TYPE

SYNTAX HeTenthdBm

UNITS "0.1 dBm"

MAX-ACCESS read-only

STATUS current

DESCRIPTION

"The output power. This could be the power from a single output or the output power from each of multiple outputs.

This object must provide for the alarm management capabilities with a corresponding entry in the PropertyTable of SCTE-HMS-PROPERTY-MIB (HMS026).

An alarm shall be recorded as an entry in the currentAlarmTable of SCTE-HMS-PROPERTY-MIB (HMS026).

A log record shall be added as an entry in the heCommonLogTable.

An heCommonAlarmEvent notification shall be sent."

::= { heOpAmpOutputEntry 4 }

heOpAmpOutputGainType OBJECT-TYPE

SYNTAX INTEGER {

```

    constantPower(1),
    constantGain(2)
}
MAX-ACCESS read-write
STATUS current
DESCRIPTION
    "Controls the output gain type, which is either constant
    power or constant gain. When constantGain is selected,
    the value of heOpAmpGainPerWavelength is used to control
    the output of the amplifier and heOpAmpSetOpticalOutputPower
    will have no effect. When constantPower is selected,
    heOpAmpSetOpticalOutputPower is used to control the output
    of the amplifier and heOpAmpGainPerWavelength will have no
    effect "
 ::= { heOpAmpOutputEntry 5 }

-- conformance information
heOpAmpMIBConformance
    OBJECT IDENTIFIER ::= { heOpticalAmplifierMIB 2 }

heOpAmpMIBCompliances
    OBJECT IDENTIFIER ::= { heOpAmpMIBConformance 1 }

heOpAmpMIBGroups
    OBJECT IDENTIFIER ::= { heOpAmpMIBConformance 2 }

-- compliance statements
heOpAmpCompliance MODULE-COMPLIANCE
    STATUS current
    DESCRIPTION
        "The minimum compliance statement for indoor optical amplifiers."
    MODULE -- this module
        MANDATORY-GROUPS { heOpAmpUnitMandatoryGroup,
            heOpAmpInputMandatoryGroup,
            heOpAmpOutputMandatoryGroup
        }
        GROUP heOpAmpUnitTableGroup
        DESCRIPTION
            "this is an unconditionally optional group"
        GROUP heOpAmpInputTableGroup
        DESCRIPTION
            "this is an unconditionally optional group"
        GROUP heOpAmpLaserTableGroup
        DESCRIPTION
            "this is an unconditionally optional group"
        GROUP heOpAmpOutputTableGroup
        DESCRIPTION
            "this is an unconditionally optional group"
    ::= { heOpAmpMIBCompliances 1 }

heOpAmpUnitMandatoryGroup OBJECT-GROUP
    OBJECTS {
        heOpAmpUnitOutputStatus
    }

```

```

STATUS current
DESCRIPTION
    "The main group defines objects which are common to all
    indoor optical amplifier modules."
::= { heOpAmpMIBGroups 1 }

heOpAmpInputMandatoryGroup OBJECT-GROUP
OBJECTS {
    heOpAmpInputPower
}
STATUS current
DESCRIPTION
    "The input group defines objects which are common to all
    indoor optical amplifier modules."
::= { heOpAmpMIBGroups 2 }

heOpAmpOutputMandatoryGroup OBJECT-GROUP
OBJECTS {
    heOpAmpOutputPower
}
STATUS current
DESCRIPTION
    "The output group defines objects which are common to all
    indoor optical amplifier modules."
::= { heOpAmpMIBGroups 3 }

heOpAmpUnitTableGroup OBJECT-GROUP
OBJECTS {
    heOpAmpUnitOutputStatus,
    heOpAmpUnitOnOffControl
}
STATUS current
DESCRIPTION
    "The unit group defines objects which are defined
    in the SCTE-HMS-HE-OPTICAL-amplifier-MIB MIB module."
::= { heOpAmpMIBGroups 4 }

heOpAmpInputTableGroup OBJECT-GROUP
OBJECTS {
    heOpAmpInputPower
}
STATUS current
DESCRIPTION
    "The input group defines optical objects which are defined
    in the SCTE-HMS-HE-OPTICAL-amplifier-MIB MIB module."
::= { heOpAmpMIBGroups 5 }

heOpAmpLaserTableGroup OBJECT-GROUP
OBJECTS {
    heOpAmpLaserTemp,
    heOpAmpLaserBiasCurrent,
    heOpAmpLaserOutputPower,
    heOpAmpLaserTECCurrent,
    heOpAmpLaserType
}

```

```

    }
STATUS current
DESCRIPTION
    "The laser group defines laser objects which are defined
    in the SCTE-HMS-HE-OPTICAL-amplifier-MIB MIB module."
::= { heOpAmpMIBGroups 6 }

heOpAmpOutputTableGroup OBJECT-GROUP
OBJECTS {
    heOpAmpSetOpticalOutputPower,
    heOpAmpGainPerWavelength,
    heOpAmpOutputPower,
    heOpAmpOutputGainType
}
STATUS current
DESCRIPTION
    "The output group defines amplifier output objects which are defined
    in the SCTE-HMS-HE-OPTICAL-amplifier-MIB MIB module."
::= { heOpAmpMIBGroups 7 }
END

```